

Effective and Economical Hydrocarbon Removal with **Enhanced Polymeric Absorbent** Cartridges

Parker Hannifin's Fulflo® TruBind™ absorbent cartridges utilize a modified polymeric absorbent that economically and effectively reduces trace hydrocarbon contamination in agueous fluids. The enhanced polymer, configured in a radial-flow-design cartridge, provides maximum utilization of available surface area. This product can be used alone or as an enhancement to other systems. Whether process fluid reclamation or meeting disposal requirements is the goal, TruBind™ can solve many demanding hydrocarbon contaminated aqueous fluid problems.

Applications

- Water Soluble Machine **Tool Coolants**
- Alkaline Parts Washing
- Industrial Discharge Water
- Produced Water Disposal
- Injection Molding Cooling Water
- E-Coat Paint
- Pre R.O. Membrane
- Tanker Ballast Water
- Aerosol Mists
- **Plating Solutions**

- Leisure/Commercial Shipping Bilge Water
- Surface Water Runoff (Truck stops, airports, auto service stations)
- Gas & Oil Facility Wastewater
- Car & Truck Wash Water
- Compressor Condensate
- Post Oil/Water Separator Polishing
- Floor Scrubbing Waste Water
- Pre Carbon Bed

Fulflo® TruBind™ Cartridges 700 Series

■ Polymeric Absorbent

Sorbent Cartridge Series



Features and Benefits

- Increases machine tool life when installed at point-of-use.
- Increases working life of valuable process fluids.
- Reduces hydrocarbon levels to meet EPA discharge regulations.
- Absorbed hydrocarbon is chemically bound by polymer and is not leachable.
- Absorbent polymer is enhanced to maximize utilization of surface area.

- Radial flow design of cartridge allows maximum flow with minimal pressure drop.
- High integrity construction withstands harsh process environment.
- Retrofits parker P, FP, FPM vessel series and PC Series Portable Cart.
- TruBind cartridges are completely incinerable

Process Filtration Division



Sorbent Series

Technology

Unlike competitive technologies in which hydrocarbons are removed through surface adsorption onto the medium, TruBind™ cartridges utilize a proprietary modified polymer that both absorbs and chemically binds the hydrocarbon molecules into its interior matrices. The affinity of the polymeric absorbent for hydrocarbon contaminant is so great that accelerated testing by the Toxic Characteristics Leachate Procedure (TCLP) indicated the effluent hydrocarbon level in water to be

below current and proposed EPA limits. The modified polymer was formulated to control the speed of hydrocarbon absorption by eliminating the potential for skin formation at the polymer/hydrocarbon interface. Consequently this polymer, when incorporated into a radial-flow-design cartridge, insures maximum utilization of surface area. The nature of the polymer makes it an effective absorbent for free, emulsified and dissolved oils, synthetic lubricants, grease and a

Performance

TruBind™ absorbent cartridge efficiency depends upon the residence time of the fluid within the cartridge, which is a function of the volumetric flow rate.

- 1. Hydrocarbon Removal Efficiency: At an equivalent flow rate of 5 gpm per cartridge the TruBind™ cartridge typically reduces trace hydrocarbon contaminant in excess of 95% in single pass mode. This efficiency level can be maintained only to a net differential pressure of 10 psi. Series or multipass filtration can virtually eliminate hydrocarbon contamination.
- multitude of organic solvents. 2. Hydrocarbon Absorbent Capacity: The

TruBind™ cartridge medium has the potential

to remove up to 1200 grams (approximately

contaminant. On this basis, the table below

gallons at several trace contaminant levels

based on a 5 gpm flow rate per cartridge.

Absorbent capacity will decrease as density

one quart) of low density hydrocarbon

provides expected life data in hours or

of hydrocarbon increases.

3. Flow Rate Capability: A maximum flow rate of 5 gpm per cartridge is recommended for the most effective removal of trace hydrocarbon contaminant.

Hydrocarbon Concentration		Hydrocarbon Removal per	Estimated Life in	Gallons Fluid	Estimated Cost per Gallon
(ppm)	(% by Weight)	Minute (grams)	Hours	Treated	of Treated Fluid
10	.001	0.189	111.39	31746	\$0.003
100	.01	1.795	11.14	3175	\$0.030
1,000	.1	17.954	1.11	317.5	\$0.29

Ordering Information

- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1							
TBC	7	18 	A				
Cartridge Series	Outside Diameter	Cartridge Length	Supp Core				
TruBind™ Absorbent Cartridge	<u>Code</u> <u>in mm</u> 7 6-1/4 159	<u>Code</u> <u>in</u> <u>mm</u> 18 18 457	A= H				

Ν DO port Seal Cartridge Seal Material Design N = Buna Nleavy DO = Double Gasket Nall Poly-Open End ethylene

Specifications

Materials of Construction:

- Absorbent: Laminated Proprietary Polymer
- Support Construction: 100% polyolefin
- Seal Material: Buna-N gasket

Cartridge Dimensions (nominal)

- Length: 18 in (457 mm)
- Outside Diameter: 6-1/4 in (159 mm)
- Inside Diameter: 2-5/8 in (67 mm) with separate support core

Maximum Recommended Operating Conditions:

- Temperature: 150°F (65°C)@20 psid (1.4 bar); 180°F(82°c)@10 psid (0.7 bar)
- Pressure: 60 psid (4.1 bar) @ 75°F (24°C)
- Flow Rate: 5 gpm per cartridge
- Changeout Pressure Drop (net): 10 psi (0.7 bar)
- Flow Factor: 0.3 psid per 1 gpm at 1 cks viscosity per cartridge
- pH range: 2 -12

Recommended Vessels:

Parker Fulflo "P". "FP". "FPM" Series and PC Series Portable Cart.

BioSafety:

■ The TruBind™ cartridge is classified as non-hazardous and incinerable. Disposal must be dictated by local regulations pertaining to the absorbed contaminant.

TruBind™ 700 Series is coreless and requires a support core prior to cartridge installation in vessel. The polyethylene core gives the cartridge sufficient strength and precludes cartridge collapse at recommended operating conditions. Support core is a reusable part and does not need to be replaced.

Part Number: 4452-5120



Process Filtration Division

Parker Hannifin Corporation Process Filtration Division 6640 Intech Boulevard

Indianapolis, Indiana 46278 Toll Free 1-888-238-5356 Telephone (317) 275-5356

Fax (317) 275-8410 http://www.parker.com/processfiltration

Bulletin C-8520 Page 2 of 2

TBC718A-DO-N

Example: